

HUAYU®

RM-D1296

English

INSTRUCTION FOR UNIVERSAL REMOTE CONTROL

Thank you for using the remote controller. When it is the first time to put in the batteries, please try it first. If it could work well with all of its functions, the product can be used directly without setting it. However, if it could not work well, it should be set with the following methods before remote controlling your TV. The remote controller would not lose its memory when the power is down so that you could replace the battery without resetting it.

Settings of Remote controller:

The remote controller has the following methods of settings, please choose any of them.

Inputting code:

- 1, Turn on your TV manually and make it in a normal play state, let the remote control aim to the front of your TV, and then find out the corresponding remote control code of your TV from the "Code Table".
- 2, Press "INPUT" and "OPEN" button together, when the indicator light, then release, enter the corresponding code. The indicator will turn off, setting to be finished.
- 3, Test the functions (such as Volume button) can work well or not. If not, repeat step 2 until you find the suitable code.

русский

Инструкция по эксплуатации универсального пульт дистанционного управления

Благодарим за использование данного пульта дистанционного управления. Перед первым использованием данного пульта необходимо вставить батарейки. В случае правильной работы всех функций пульта, дальнейшая настройка пульта не требуется. В противном случае, для корректной работы пульта, необходимо будет произвести настройку, одним из способов, представленных ниже. Настройки пульта постоянно хранятся в памяти, поэтому после замены батареек повторную настройку пульта производить не нужно.

Настройка пульта
дистанционного управления:

Настройку пульта можно произвести одним из следующих способов.

Ввод кода:

1. Включите вручную телевизор, направьте пульт на телевизор и найдите соответствующий вашему TV пульт в «Таблице кодов»
2. Нажмите кнопки «INPUT» и «OPEN» одновременно, когда индикатор загорится – отпустите обе кнопки. Введите соответствующий код. Индикатор погаснет – настройка завершена.
3. Проверьте функции (например кнопки регулировки звука). Если эти кнопки не работают, то повторите пункт 2, пока не найдёте подходящий код.

INPUT OPEN



INPUT OPEN



Technical parameters:

Remote Controlling Distance:
About 10 meters (varies by
different types). Battery Type: two
pieces of AAA Batteries.

Технические характеристики

Дальность действия пульта: до 10 метров, в
зависимости от модели пульта.
Тип батареек: 2 батарейки AAA.

000



AKB73636108

002



AKB37026854

003



AKB37026874

004



AKB73315302

005



AKB37026872

006



AKB37026852

007



AKB37026853

008



AKB37026822

009



AKB69491501

010



AKB37026832

011



AKB72216901

012



AKB72216902

013



AKB72216901

014



AKB72216902

015



AKB70877912

016



AKB36087433

017



AKB36087434

018



AKB70877909

019



AKB72413303

020



AKB70877935

strong.com.ru