



Instruction for UNIVERSAL LCD/LED TV REMOTE CONTROLLER

000



AOC
AOC

002



GENERAL
LCD-831

003



GENERAL
LCD-832

004



IZUMI
TL19H405B

005



IZUMI
0152

006



EN
30303D

010



HOB301
MYSTERY KT6957 6857

011



HOB117
AKIRA TC1860F1

012



HOB187
GK23J6-C15

013



HOB279
AKIRA LCT-15CHST

014



4-3-2010-002

015



BBK
BBK

016



BBK
EN-31603B

017



HOB158
BBK LT1504

018



HOB332
BBK CAMERON

019



HOB380
RC2465

020




HOB387
RC-2603

021



HVD208
BBK

022



HVD209
RC1529

023



HOB228
LCD 831

024



HOB283
SUPRA 4625TV-LC1504

025



HOB302
HYUNDAI 1587 RCF1B

026



HOB303
SUPRA306 STV-LC1515

027



HOB327
Supra RC3b

028



HOB328
Supra RCF3b

029



HOB409
SUPRA Y-72C2

030



HOB410
SUPRA RC6b

031



HOB411
SUPRA RC12

032



RCF1B
RCF1B

033

SUPRA
BD-212

034

SUPRA
HOF12H126GPD11

035

SUPRA
RC1b

036

SUPRA
RC5b

037

SUPRA
RC5db

038

SUPRA
RC13b

039

SUPRA
RC-118-0B

040

SUPRA
STV-LC2615ED

041

HOB168
SHIVAKI BT0451C


042

HOB231
SHIVAKI 02

043

ROLSEN
ER-31607R

046

HTC056
RC1994907-01

047

HTC058
RC198

048

HOB333
81E829

049

HOB394
81E503

050

HOB227
ORION

051

HOB252
OPENBOX-1253

052

HOB281
MYSTERY 5195


053

HOB282
MYSTERY 8151

054

HOB301
MYSTERY KT6957 6857

055

HOB326
MTV-1914LW

056

MESTERY
LCD LED TV NEW

057

HSR499
HIVION

058

HOB402
ISTAR

059

HOB403
ISTAR

060

HOB405
ISTAR

061



ER-31607

062

HOB438
ER-31607R-1098#

063



LCD-2277RC

066

HOB302
HYUNDAI 1587 RCF1B

067

HOB376
H-LCD2202GCOVA10285J

068

HOB390
CH-2145

069

FUSION
RC3b_1042

070

HOB198
FUNAI 48KEY

071

IR1628
FUNAIPC2

073

HOB018
ELENBERG Y27401

074

HOB354
ELENBERG

079

HOB151
BERICOM008

080

HOB189
HOB189

081

HOB264
RC-A3-01

082

HOB273
HOB273

083

HOB373
EN-21662B

084

HOB223
RC-L-05

085

HOB225
RC-L-06

086

HOB108
ACH-P-2

087

HOB149
BERICOM006

088

HOB150
BERICOM007

089

HOB206
EL-41UA299

090

HOB329
T15E01MT

091

HOB330
H-LED32V6

092

HOB341
STV-LC1914W

093

HOB418
ZD-RC30

094

DMTECH
DMTECH

095

HOB262
HOB262

096

HOB344
HOF45A1-2

097

HOB249
PARS

098

HOB292
H502-2

099

HOB013
HOF-54B1.4

100

HOB339
GI S2138

101

HOB381
HOF12E148GPD5

102

HOB346
HOF10G705GPD9

103

SONIQ
QT-112

104

SUNSTECH
TL1970HD

105

HOB195
H-LCDVD2200

106

HOB196
HOB196

107

HOB314
Singer LCDKZG-108

108

HOB386
RM-611

109

HOB308
IR1492 SENCOR

110

HOB310
HOB310

112

HOB342
STV-LC1985WL

113

HOB382
GI HOF12B441GPD11

114

HOB220-NF021RD
NF020RD-NF031RD-NF036RD 4IN1

115

NF039RD
NF039RD

116

PC221
01

117

PC221
02

120

BC10SB
BC10SB

121

daytron
LCD TV

122

HOB358
RC-A03

123

RC
A06

124

RC
A10

125

TLCD
32HD-TELEFUNKEN

126

KAIMY
KAIMY

127

acer
acer

130

HOB162
BERICOM009

131

HOB187
GK23J6-C15

132




LCD-2699

133

HOB229
OPTICUM9600 TS20

134

HOB242
RC1994925

135

HOB253
SNOWA

136

HOB331
AKAI A4001032

137

HOB353
KM1128

138

HOB368
S5 S6 S7 S8 S9

139



LCD-2318

140

HOD142
HOD142

141

HOD148
VT-L9A11

142

HSR553
CYFROWY POLSAT

143

HSR585
IPM PLATFORM

144

Singer LCD TV
901-7650-315G1G

145

LCD
TV FU-1

146

LCT
01

147

LCT
02

148

148
148

149

HOB393
1253

150

12-17-2011_001
B0063715



365

HOB455
ELECTRON T-81100

366

HOB457
RL-32L700U 3D

367

HOB464
BRAVIS LED2868 HQ

368

HOB465
DIGITAL DLE-4011

370

HOB46
LUXEON LED3213 HQ

371

ORION EP
22 LCD2623

372

HOB493
HAIER

373

HOB494
SUPRA

374

HOB498
SHOWNIC

375



LEA-19V07P

376



IZUMI

377




81F579

378




ORION OR-LCD2

379



FUSION RC21b

380



SUPRA RC6w

381



SUPRA RC8b

382



SUPRA RC10w

383



SUPRA RC18b

384




RC-LEM100

385



BBK RC-LEM101

386



BBK RC-LED100

387



IZUMI_TL26H211B

388



JAC

389



SKY LINE

390



TRUMAN

391



union tech

396



ATLAS HD100

397

HOB688
ATLSS HD-2005

398



KK-Y331J

399



KK-Y331J

400



HD LED100

401

GBTY
ONGOV59

402



XY-B02E

403



LCD TV PHONAR

405

PHONAR
LED TV

406



DAWA MV

407



IDEA

408



IDEA

409



IDEA

410



IDEA

411



IDEA

412



IDEA

413



IDEA

414



IDEA

415



AOC-02

416



DEX LT-2220

417



ORION LED2643

418



Akai SLP-006P


419

Fusion FLTV
22H11

420

Fusion FLTV
32H17

421



FUSION RC156

422



Shivaki K77

423



Shivaki K78

424



Supra TV-DVD

426



RC-GK22G1

427



H-LCD3210

428



LED321LC

429




SKYPRIME HD

430


SUPRA
RC21b-1219

431



ORION LCD

432



TC1860F1-RS

433



JH-11370

434




IFD-851

435



RC-D3

436



YC-53

437



STV-22LED5

438



LED-EH4720BF

439



DNS M28AM8

440



051D RED

441



33585

442



RC33729

442



HOB842

442



34090

442



34091

443



RC31277

444



Fusion RC25b

445



RCF23b

446



RC-E23

449



AKI AK61

450

AKI LCD
AK66

451

AKI LCD
AK68

452

AKI-OND
IGO LCD

453



ONIDA LCD

454

ONIDA LCD
ON87

516



051D BLACK

520



SNOWA51163

528



BLAUPUNKT

531



J-1274

540



MERTER33186

542

BRAVIS
LED-1615

500



STV-42LED5

544

ONIDA
LCD1

545

Akai
HOF08J001

546



Polar 94LTV6004

547

AN-LT3222
AN-LT3225
AN-LT2416

548

FUSION
HY-079

549


SATURN
LED40FHD500U

540



DEXP 16A3000

540



RUBIN RB-28D7T2C

550



DNS S19ASL1

551



RM-NST60

533



RM-SK09

strong.com.ru

B0063716