


Разъем Pioneer KEH-1300

Описание:

Разъем для Pioneer KEH-1300

Применяется для подключения акустики, питания и управляющих проводов к автомагнитоле: PEONEER KEH-1100 KEH-1700 KEH-2730 R KEH-P-3630 R; KEH-1150; KEH-1730; KEH-3520; KEH-P-4300; KEH-1200; KEH-1800; KEH-3700; KEH-P-4400; KEH-1300; KEH-1830 R; KEH-3710; KEH-P-4500; KEH-1300 K; KEH-2100; KEH-3720; KEH-P-4530; KEH-1300; SDK KEH-2300; KEH-3730; KEH-P-4600; KEH-1311; KEH-2400; KEH-5700; KEH-P-4700; KEH-1400; KEH-2520; KEH-5730 R; KEH-P-4730 R; KEH-1450; KEH-2700; KEH-P-3300; KEH-P-5700 R; KEH-1500; KEH2710; KEH-P-3400; KEH-1530; KEH-2720; KEH-P-3600.



Цвет провода	Описание	
Red	To electric terminal controlled by ignition switch (12 V DC) ON/OFF.	
Black (chassis ground)	To vehicle (metal) body.	
Yellow/black	If you use a cellular telephone, connect it via the Audio Mute lead on the cellular telephone. If not, keep the Audio Mute lead free of any connections.	
Orange	To terminal always supplied with power regardless of ignition switch position.	
Blue	To system control terminal of the power amp. (Max. 300 mA 12 V DC.)	
Green (+)	Left	Front speaker
Green/black (-)		Rear speaker or Not used
Green/red (+)		
Black/green (-)		
Gray (+)	Right	Front speaker
Gray/black (-)		Rear speaker or Subwoofer
Gray/red (+)		
Black/gray (-)		